

Clean Data

Getting Rid of those Pesky Artifacts in your Data



The Signal and the Noise


$$\text{SNR} = \frac{P_{\text{signal}}}{P_{\text{noise}}} = \left(\frac{A_{\text{signal}}}{A_{\text{noise}}} \right)^2,$$

$$\text{SNR} = \frac{\mu}{\sigma}$$

*the signal and the
and the noise and
the noise and the
noise and the no
why so many and
predictions fail—
but some don't t
and the noise and
the noise and the
nate silver noise
noise and the co*

Effects of Noise on Decision-Making

ROC Curve



“Noise” vs. “Artifacts”

Type 2 Error / “Beta” Error




Type I Error / “Alpha” Error




Artifacts can be...

1. Mechanical, Biological, or Psychological, in Origin.
2. Systematic or Random in Time.
 - Can't I just average it out?
3. Stationary or Nonstationary in Space.
 - Can't I just regress it out?

A Priori Power Analysis




How Powerful is your Data?



The Artifact Action Plan

$$\text{SNR} = \frac{P_{\text{signal}}}{P_{\text{noise}}}$$



I) Collect Powerful Data from the Start




2) Record Your Artifacts Directly

- Makes it easier to interpret your data.
- Examples:
 - Eye Movements: EOG Channels, Eyetracker
 - Muscle Activity: EMG Channels
 - Heart Activity: EKG Channels
 - Head Movements: Head Coils (MEG)
- Don't rely on clear artifact signals in your brain data for source separation!


Visual Artifact Rejection

- Advantages:
 - Simple, Powerful
 - Makes other methods more effective
- Disadvantages:
 - Time Consuming
 - Subjective
 - Leaves less data to work with


Bad Channel / Power Line Noise



Eye Movements




Muscle Activity / Biting




Semi-Automatic Artifact Rejection

- Uses Data Statistics to find artifact-containing time points.
 - The more well-behaved the artifacts, the more powerful this step will be.
- Some Statistics commonly in use:
 - Data Moments:
 - Mean, Variance, Skewness, Kurtosis.
 - Correlation with Artifact Channels
 - Entropy
- Be Conservative:
 - Three small rejections is better than one big one.

Skewness




Kurtosis




Artifact Correction

- Linear Regression with Artifact Channels
 - Requires full recording of artifacts
 - Assumes linear relationship between artifact (a.k.a “nuisance”) channels and data channels.
 - Assumes a single relationship between artifact and data channels.
 - May helped by adaptive filtering of nuisance channel.
- Data Decomposition
 - Ex) Independent Component Analysis
 - Many ICA algorithms exist: INFOMAX, FASTICA, JADE, etc.
 - Source Separation Requires many data channels
 - Many algorithms are slow, can take a while.


Artifact Components: Vertical Eye Movements



Artifact Components: EKG



Reducing Noise: Principal Component Analysis




Take Home Messages

- “Garbage In, Garbage Out”.
 - Collect enough high-quality data to detect the signal you are interested in!
- Be Conservative.
 - Be careful of selection bias!
 - Use multiple strategies to remove artifacts.
 - Don't rely too much on a single method.
- Artifact Channel \neq Artifact Type

What is your Artifact Action Plan?

$$\text{SNR} = \frac{P_{\text{signal}}}{P_{\text{noise}}} = \left(\frac{A_{\text{signal}}}{A_{\text{noise}}} \right)^2 = \frac{\mu}{\sigma}$$



Thank You!